


Providing Repeater Facility for any GUIDE System

Product Overview

- Syncro GUIDE Repeater is an additional facility for the Syncro GUIDE fire alarm management system.
- GUIDE Repeater allows monitoring and limited control of the Syncro fire control system to be repeated on dedicated computers connected to the building Local Area Network.
- GUIDE Repeater is highly configurable allowing replication of the main GUIDE system or alternative information to be given at the repeater

Features

- Up to 16 GUIDE Repeaters may be connected to a single GUIDE system
- All monitoring options on GUIDE are supported on the GUIDE repeater. Device and zone disablements may also be performed from the Guide repeater.
- Choice of text, graphics, combined display when an event occurs.
- Easy to use
- Allows graphical information of fire events to be shown at alternative locations
- Unlimited map linking and zoom facility
- Display and control for up to 64-networked Syncro panels



Guide Repeater user interface

Range

Product Code Description

GR2001	GUIDE Repeater - single repeater package
GR2004	GUIDE Repeater - 4 repeater package
GR2016	GUIDE Repeater - 16 repeater package

Technical

	Recommended Minimum	Notes
Processor	Intel Pentium 1Ghz	The faster the better, 2Ghz will provide future proofing.
Operating system	Windows® XP/Vista	Will operate under Windows® 2000
Memory	256MB minimum	The larger the better.
Hard disk	10GB minimum	>20GB would be better.
Graphics	1024 x 768 16M colours	The driver must allow this mode with large fonts. Separate Graphics card with 256MB graphics memory recommended
Sound card	Any PC sound card	
Loudspeaker	Any PC speakers	More convenient if built into PC.
Monitor	Any that supports above graphics driver	17 inch minimum recommended, the larger the better. (1024 x 768)
Pointing device	Mouse essential	Third button and wheels are supported. Touch screen option supported
Printer	Optional	Any type.
Parallel port	Optional	Required if parallel printer to be used.
Network	One network port	
CDROM drive	Any	Required for installation of software and updates.
Backup drive	CD Writer	To back up history.

Specifications

